

Installing a Hook on Display.

- The 2 cables need to be 500mm apart with the total display measuring 1000mm in width.
- Having marked out the floor positions, use a plumb bob to find the location on the ceiling directly over the floor position.
- Unscrew the fixing plate from the ceiling fixing (small end) and securely fix to your mark on the ceiling.
- Do the same to the floor with the fixing plate from the cable tensioner.
- Hang the cable from the ceiling fixing allowing it to unwind.
- Undo the small brass fitting attached to the cable inside the tensioner with the 1.5mm allen key provided, slide this up the cable and with the cable pulled tight, retighten this fitting flush with the top edge of the floor fixing.
- Cut off the cable so that it sits 5mm below the top edge of the floor fixing.
- Screw the outer body of the tensioner onto the floor fixing.
- You should feel the tension starting to be taken up just before the tensioner is screwed fully down.

Note. Check that the cable will pull gently out against the spring. If there is no movement the tension is too strong and the brass fitting needs to be moved down the cable.

Remember, the cable is only as strong as your ceiling fixing.

- Mount the CC08's onto the cables, making sure that you have a support at the same level on each cable.
- Slide the rod into these supports so that it sits at 90 degrees to the cable.
- Check the first rod is level with the floor so that the pocket will hang correctly.
- When the rod is positioned so that there is an equal overhang at each end, tighten the grub screws in the CC08's.
- Add an end cap to each end of the rod.
- Once you are happy with the position of the top rod, repeat this operation with the second rod. Before tightening.